

Assembly Instructions for 90 Degree Corner Bay

1



Locate the baseleg rear lug and block into the bottom "H" Slots of the upright as shown.

2



Using a rubber mallet, firmly knock the baseleg upwards locking it into position until flush.

3



Repeat steps 1 and 2 until you have two "L" shaped uprights.

4



Connect all "L" shaped uprights together by fitting 665mm back panels into the bottom "H Slots" of both left and right hand side uprights to the central upright. Now check levels are correct by adjusting the foot discs as required. *

5



Fit the plinth skirting into position by slotting it between the front capping on the baselegs.

6



Fit the base shelf onto the baseleg runners. Now fit all remaining back panels.

* Note: Back panel lugs locating into the central upright must be sent to a 45 degree angle prior to installation.

Assembly Instructions for 90 Degree Corner Bay

7



Once the base shelf and back panels are in place the bay should look as above. You are now ready to fit the upper shelves.

8



Use two pairs of brackets as per upper shelf. Insert a single bracket into the left upright and a single bracket into the right upright. Then insert the other pair of brackets into the central upright.

9



Fit a matching shelf onto the brackets.

10



Repeat steps 8 - 9 until all the upper shelves are in position.

11



To finish use 665mm EPOS ticket strips and cut to suit the size of the shelf. Attach the EPOS ticket strips to the front of all shelves.

12



To further assist your installation please see the above exploded bay configuration.